



LIFTED PRODUCTIONS®

The LIFTED PRODUCTIONS Game Head 70 wireless gaming headset



User Manual

Contents

1. Important Safety Information

Hearing Safety

General Information

2. Your Bluetooth Headphones

What's inside the box

Other Devices

Overview of your Bluetooth headphones

3. Getting Started

Charging your headphones

Pairing a Bluetooth device

4. Using your headphones

Connecting to a Bluetooth device

Battery indication

Quick Start Guide

5. Technical Specifications

6. Notices

Declaration of conformity

Disposal of your old product and battery

Compliance

Trademarks

7. Frequently Asked Questions

1. Important Safety

Instructions

Hearing Safety



- To avoid hearing damage, limit the time you use the headphones at high volume and make sure you set the level to a safe level. The louder you play the volume the shorter the listening time is.

Please pay attention to these guidelines when using your wireless headset.

- Listen at reasonable volumes for reasonable periods of time.
- Be careful so as not to adjust the volume so high you can't hear what is around you.
- Use caution or discontinue use in potentially hazardous situations.
- Excessive sound pressure from earphones or headphones can cause hearing loss over time.
- Using headphones with both ears covered whilst driving is not recommended and may even be illegal in some areas whilst driving.
- For your own safety, please avoid distortions from music or phone calls while in traffic or other potentially dangerous environments.

General Information

To avoid damage or malfunction



- Do not expose your headphones to excessive heat.
- Do not drop your headphones.
- Headphone should not be exposed to dripping or splashing.
- Do not submerge your headphones in water.
- Do not use cleaning agents containing alcohol ammonia, petrol or abrasives.
- If cleaning required please use soft, if necessary slightly dampened with a minimum amount of water or diluted mild soap, to clean the product.
- The integrated battery should not be exposed to excessive heat such as sunshine, fires or the like.
- Danger of explosion if the battery is incorrectly replaced.

Operating, storage temperatures and humidity.

- Operate or store in a place where the temperature is between -15°C (5°F) and 55°C (131°F) - up to 90% relative humidity.
- Battery life may be shortened when in high or low temperature operating conditions.

2. Your Bluetooth Headphones

Congratulations on your purchase of the Game Head headphones and welcome to Lifted Productions!

You can visit our website for further products and more information at: www.liftedproduction.com

These are not ordinary wireless headphones, they include the very latest in Digital Signal Processing (DSP) for your 3D surround sound enjoyment. With these headphones you can:

- Enjoy all the convenience of wireless operation.
- Use these with your PC, laptop or tablet.
- Listen to music, watch films or play games,
- Use any of the three built-in modes: X-bass>Video>Game.
- Enjoy gaming with any BT enabled device
- Use with your PS4, Xbox or Switch gaming devices.
- Compact design easy to carry around.
- Great for both male and female gamers.
- Enjoy all this whilst on-the-go!

What's inside the box

- The GH70 headset
- Detachable professional microphone cable with microphone for gaming
- A long USB charging cable
- A Quick User Guide

Other Devices

These headphones will work with Bluetooth enabled devices such as mobile phones, tablets, PCs, laptop computers, MP3 players, PS4, Xbox, Switch and devices compatible with these headphones (See Technical Specifications on page 6).



Overview of your Bluetooth headphones



- Micro USB port
- Power on/off
- Internal microphone
- Detachable external microphone
- Charging on/off
- Bluetooth LED indicator
- Modes: X-bass>Video>Game
- Volume, skip track backwards
- Volume, skip track forwards
- Play/pause, calls

3. Getting Started

Charge your headphones



- Before using your headphones for the first time charge the battery for up to 5 hours for optimum capacity and battery lifetime.
- Use only the original USB charging cable to avoid any damage.

Connect the supplied USB charging cable to the micro USB Charging slot on the headphones (see above). The LED light on the side of the headphones turns red whilst charging and turns off once the unit is fully charged.



- A normal charge typically takes 2.5 hours.

Pairing a Bluetooth Device

To pair a Bluetooth device please follow these simple steps:

- Activate the BT feature on our device, using the phone menu to “add” or “search” or “scan” for new Bluetooth devices.

The Bluetooth feature is usually found in the Settings Menu of the device.

iPhone: Settings>Bluetooth>ON (starts the search)

Smartphones: Settings>Options>Bluetooth: on>searches for devices.

Android Smartphone: Settings Bluetooth: on>scans for devices.

- Activate Bluetooth pairing mode by sliding the Power Switch on, the pairing mode will start automatically. The blue LED light should then flash slowly under the search mode, flashing frequently when successfully paired.
- Select “Game Head 05” from the list of Bluetooth names showing on the device. The headset LED light should then be flashing frequently following successful pairing.
- You can now enjoy wireless freedom for your gaming, home entertainment or music and calls.

4. Using your headphones

Connect to a Bluetooth device

- Turn on your mobile phone or Bluetooth gaming device.
- Slide the Power Switch on, the pairing mode will start automatically.

- The blue LED light now flashes.
- The headset will first reconnect to the last paired BT device automatically, If the last connected device is not available, the headphone will be in pairing mode waiting for the new device to be connected. You can now choose to pair the headphone with your mobile phone.



- If you turn on the Bluetooth device or activate the BT feature after turning on the headphones, you will have to reconnect the headphones and Bluetooth device manually.








- If the headphones did not connect with any Bluetooth device after 5 minutes, power off and turn it on again and follow the steps in Section 3 (page 5) for BT pairing.

Battery indication

Turn on the headphones	Slide to the ON position, and a blue light flashes by the M symbol when unit charged
Low battery level	The LED flashes 3 times every 10 seconds until the unit is completely out of power.
Battery is fully charged	LED is off.

Quick Start Guide

Please refer to the quick start guide provide with this product. The overview of the headset functions is given below.

Power on/off switch	Slide to ON position to turn the unit on. Slide to OFF position to turn off the headset.
Micro USB port	For charging the headset.
Hidden microphone	For hand free operation on calls
Volume DOWN Skip backwards	Short press to turn the volume down, long press to skip the music track BACKWARDS.
LED Indicator 	RED LED light shows when X-Bass mode is selected.
Play/Pause and call 	Press symbol for MUSIC play and pause functions, press to pick up any incoming calls.
LED Indicator 	RED LED light shows when the VIDEO mode is selected.
LED Indicator 	RED LED light shows when the GAMING mode is selected.
Volume UP Skip forwards	Short press to increase the volume and long press to skip the music track FORWARD.
Sound Modes 	Modes are a cyclic operation from X-Bass>Video>Gaming to select the required sound mode.
Bluetooth LED	Flashes slowly whilst in search mode, flashes frequently when pairing is successful.

5. Technical Specifications

Product technical details

These headphones incorporate the very latest in 3D surround sound technology powered by Digital Sound Processing technology to deliver the best sound for your lifestyle.

Bluetooth Version	V.4.1
Supported Profiles	A2DP, AVRCP,HSP,HFP
Range	Up to 10 metres (30 feet)
Driver Type	40mm PET diaphragm
Impedance	32 Ohms
Sensitivity	103dB +/- 3dB @ 1Hz
Output Power	40mW + 40mW
Battery Type	Li-Polymer (800mAh)
Playback Time	Typically 8 hours
Charge Time	2.5 hours
Talk Time	12h
3D Sound DSP	Specially tuned
Attachable Audio Mic	Sensitive cable microphone for clear group chats while online gaming.



- Specifications subject to change without notice.

6. Notices

Declaration of Conformity

Lifted Productions (HK) Ltd, hereby declares that this product is certified according to the provisions of the R & TTE Directive (99/5/EC) which declares that this device is in compliance with the essential requirements of the Directive 1995/5/EC.

Battery disposal



Your headphones are designed and manufactured using high quality materials and components, which can be recycled and reused.



This symbol means that the product contains a built-in rechargeable battery covered by the European Directive 2013/56/EU which cannot be disposed of with normal household waste.

We strongly advise you to take your old product to an official waste collection point or have a professional remove the battery. Please inform yourself about the local separate collection systems for electrical and electronic products and rechargeable batteries. Follow local rules and please never dispose of the product and rechargeable batteries with your normal household waste.

Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human life.

Environmental Information

All unnecessary packaging has been omitted.

We have tried to make the packaging easy to separate into materials: cardboard (the box), tray (PET) and polythene (bags, protective foam sheet etc).

The product consists of material which can be recycled and reused is disassembled by a spliced company.

Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Please respect the environment.

Trademarks

Bluetooth word mark and logos are the registered trademarks owned by Bluetooth SIG Inc.

The trademarks, Brand Nation Media, Brand Nation, "LP", and LIFTED PRODUCTIONS are all owned by Lifted Production LLC and are registered both in the EU and USA.

7. Frequently Asked Questions

My Bluetooth headphones won't turn on.

The battery level is too low, charge the headphones.

Why can't I pair the Bluetooth headphones with my mobile phone?

The Bluetooth function is not enabled. Make sure you have enabled the BT function on your mobile phone first and turn on the mobile phone before the headphones.

The pairing doesn't work.

Go to settings on your mobile phone or device (see section 3 above) and carefully follow the steps. Make sure you start with your mobile phone first if that is the device you are pairing.

Check to see if the blue LED light is flashing slowly. If another device, turn on the device, go to settings and follow the simple instructions under section 3 above.

My mobile phone cannot find the headphones.

The headphones may be connected to a previously paired device, so turn off the connected device or move it out of range.

Then long press the Play/Pause button longer than 3 seconds, to reset BT connection of the headphone. A beep sound will be heard confirming reset. Follow steps in section 3) for Bluetooth pairing.

Why Bluetooth headphones are connected to a Bluetooth stereo enabled mobile phone but music only plays on mobile phone speaker.

Refer to your phone instructions and select listen to music through the headphone option.

The audio quality is poor with crackling noises can be heard.

The Bluetooth device is out of range (see above its 10 metres), reduce the distance between your headphones, or remove any obstacles between them.

The audio quality is poor when streaming from my mobile phone, its very slow or doesn't work at all.

Check to make sure your mobile phone supports not only (mono) HSP/HFP but also supports A2DP (see technical information on page 7).

I can hear but cannot control music on my Bluetooth device (like play/pause/skip forward and backward).

Check and make sure that the audio device supports AVRCP (see technical information on page 7).

I am having problems using the headphones with my PC that has Windows 10 installed.

PC users using the above operating system can experience connectivity problems when connecting with Bluetooth wireless devices. Please refer useful troubleshooting websites for this known problem such as plugable.com.

My Google/Siri Assistant doesn't work.

Make sure the App is installed onto your mobile phone (see getting started above). Make sure the headphone is paired with your mobile phone then press the Play/Pause button TWICE on your headphone to activate it.

For further support you can email us on info@liftedproduction.com



LIFTED PRODUCTIONS

The GAME HEAD 05 Headset

All rights reserved. © Lifted Productions is a registered trademark of Lifted Productions LLC. This product has been developed by, and is sold under the responsibility of Lifted Productions who are the warrantor in relation to this product.

